



How to Calibrate Clear Paper for B21 Printer

If you change clear paper, but the printer keeps delivering paper and can't be stopped. Please use the following methods:


1. Open the lid and put in clear paper.
2. Connect the printer with Niimbot APP.
3. Click 'Me' -- 'My device'.



4. Click 'Paper calibrate'.



5. Click 'transparent'.



6. After the paper calibration is completed, please remove the clear paper and restart the printer. Then re-load the clear paper to start printing